Temperature Control VOC Concentration 4 Binary Inputs / Outputs



# **Product Page**

# The KNX-Sensor Neo-TC-VOC-x is used for measuring and controlling indoor air parameters

- Air temperature ( sensor in the housing ) also weighted with external temperature
- VOC level (volatile organic compound) (sensor in the housing)
- Control functions for heating and cooling applications ( can be combined )
- Setpoint temperatures for Comfort, Standby, Economy and Protection, selectable via KNX HVAC objects
- · Setpoint change via objects
- · Storage of minimum- and maximum-temperature
- · Heat- and frost-alarm
- · Limits for temperature
- · Fan control by VOC limits and external inputs
- Adaptation for setpoint and maximum temperatures
- Controller output 0...100% or programmable PWM for thermal actuators
- Valve rinse function
- Second temperature controller as auxiliary controller

#### Four binary inputs / outputs (floating)

- Light control as switch / button with short, long, double and both function
- Dimmer
- Blind and shutter control
- Programmable Encoder
- Temperature adjustment
- The binary inputs can be configured as outputs ( LED / Beeper )

Four logic blocks for the logical link between internal and external signals.

- 10 associated logic inputs / outputs
- · Heat- and cooling-request as additionally available signals
- Functions "AND, OR, NOT, XOR" for binary logic
- Functions "+ \*" for 8-bit values
- Function "=" for conditional forwarding of events

# **Applications**

- Detection and control of room temperature
- Detection of VOC level
- · Decentralized control for steady KNX-valves or thermal actuators
- · Decentralized ventilation control depending on air quality
- Evaluation of external switches and push buttons for switching functions





e1

Subject to change Page 1

 Arcus-EDS GmbH
 Rigaer Str. 88 , 10247 Berlin
 Tel.: +49 / (0)30 / 2593 3914

 www.arcus-eds.de
 sales@arcus-eds.de
 Fax.: +49 / (0)30 / 2593 3915



Temperature Control VOC Concentration 4 Binary Inputs / Outputs



e1

# **Startup**


The KNX Sensor is set up using the ETS ( Version 4 or higher ) and the applicable application program.

Application for ETS from version 3f on request.

The sensor is delivered unprogrammed.

All functions are programmed and parameterized with ETS.

Please read the ETS instructions.



# **Assembly**

The **Neo-TC-VOC-x** sensor is designed for mounting in a standard flush-mounted socket (60/68) mm and is located in an IP20 plastic housing with aluminum cover.

# In Case of Bus Voltage Recurrence

All changes made using the help key for the KNX bus are saved if the device has been correctly parameterized..

By using the weighted mixture temperature, the external temperature scaling is set to 0% until an external temperature value is received.

The measuring and control values start with their current values ( integral component=0 by PI-Controller ).

The ETS parameter settings are retained.

### **Discharge Program and Reset Sensor**

In order to delete the programming (projecting) and to reset the module back to delivery status, it must be switched off (disconnect the KNX bus).

Press and hold the programming button while reconnecting the KNX bus and wait until the programming LED lights up ( approx. 5-10 seconds ).

Now you can release the programming button.

The module is ready for renewed projecting.

If you release the programming button too early, repeat the aforementioned procedure.

Subject to change Page 2



Temperature Control VOC Concentration 4 Binary Inputs / Outputs



# **Technical Data**

### Technical Data - Neo-TC-VOC-x

| Measurement                              | Temperature, VOC Concentration   |
|--|--|
| Control                                  | integrated   |
| Temperature Range                        | 0 +50°C  |
| Accuracy                                 | ± 0,3°C  |
| Resolution                               | ± 0,01°C   |
| Measurement Range VOC                    | 450 - 2000 ppm CO2 equivalents   |
| Binary In- / Output                      | 4  |
| Operating Voltage                        | KNX Bus Voltage 21 32VDC   |
| Power Consumption                        | approx. 240mW ( at 24VDC )   |
| Environment Temperature KNX-Module       | Storage: -20 +50°C<br>Operating: 0 +50°C   |
| Environment Humidity KNX-Module          | 0 95% r.H Non Condensing   |
| Bus Coupler                              | integrated   |
| Auxiliary Supply                         | not required   |
| Startup with the ETS Version 4 or higher | HLK305   |
| Curcuit Points                           | KNX 2-pole clamps ( red / black )  |
| Protection Class                         | IP20   |
| Housing KNX-Module                       | Cover aluminum anodized (black) square: (80 x 80 x 6) mm round: Ø 84 x 6 mm  |
|  | Standard flush-mounted socket ( 60/68 mm ) in the dry interior   |
| Article Number                           | 30513563 Aluminum, square, sanded<br>30513564 Aluminum, square, sanded, black<br>30513663 Aluminum, round, anodized<br>30513664 Aluminum, round, anodized, black |





Temperature Control VOC Concentration 4 Binary Inputs / Outputs



e1

### **Imprint**

Editor: Arcus-EDS GmbH, Rigaer Str. 88, 10247 Berlin

Responsible for the contents: Hjalmar Hevers, Reinhard Pegelow

Reprinting in part or in whole is only permitted with the prior permission of Arcus-EDS GmbH.

All information is supplied without liability. Technical specifications and prices can be subject to change.

#### Liability

The choice of the devices and the assessment of their suitability for a specified purpose lie solely in the responsability of the buyer. Arcus-EDS does not take any liability or warranty for their suitability. Product specifications in catalogues and data sheets do not represent the assurance of certain properties, but derive from experience values and measurements. A liability of Arcus-EDS for damages caused by incorrect operation/projecting or malfunction of devices is excluded. The operator/project developer has to make sure that incorrect operation, planning errors and malfunctions cannot cause subsequent damages.

### **Safety Regulations**

Attention! Installation and mounting must be carried out by a qualified electrician.

The buyer/operator of the facility has to make sure that all relevant safety regulations, issued by VDE, TÜV and the responsible energy suppliers are respected. There is no warranty for defects and damages caused by improper use of the devices or by non-compliance with the operating manuals.

#### Warranty

We take over guarantees as required by law.

Please contact us if malfunctions occur. In this case, please send the device including a description of the error to the company's address named below.

#### Manufacturer



### **Registered Trademarks**



The CE trademark is a curb market sign that exclusively directs to autorities and does not include any assurance of product properties.



Registered trademark of the Konnex Association.

Subject to change Page 4